

# UTENSILS RACK INSTALLATION GUIDE

## STEP 1

- Before you begin the installation of your new RQ Home Utensil Rack please remember that a typical backsplash is 18" from the countertop to the cabinets. The rack needs room for your longest utensil. If you are not using the Krona® set please measure your longest utensil and hang the rack at the appropriate height.
- For the Krona® utensils we recommend about 15 inches from the countertop to the bottom of the rack.
- Please be sure the rack is level either by using a bubble level or measuring up from your countertop to both ends of the rack's bottom edge.
- Place a screw in each mounting hole and twist lightly by hand to mark the spots on the wall where you will drill. If you are having difficulty marking the spot place a strip of masking tape on the wall to receive the mark.



## STEP 2

- Carefully drill (2) 3/16" diameter holes using the appropriate drill bit for the surface.
- Please ask your contractor, hardware store or home-center for the type of bit recommended for drilling into your back-splash material; e.g. ceramic tile, natural stone, sheetrock, glass etc.



## STEP 3

- After the holes are drilled place an anchor into each hole and tap gently until the flanges are tight against the wall.



## STEP 4

- Using a Phillip's head screw driver carefully screw the rack in place. Be careful not to over tighten as the screws and anchors may become loose.
- We do not recommend using a screw gun for STEP 4 to avoid slipping and scratching the rack.
- Hang your Utensils.
- ENJOY!

